

CARVANA HAS YOU COVERED

Whether you are a first time buyer, a repair wizard, or on a strict budget, we’ve got you covered.



\$0 Dollar Deductible
at Preferred Repair Facilities



Roadside Assistance



Flexible Service Locations



Cancel Anytime

Affordable options for everyone



Basic Mechanical Coverage

CarvanaCare Essential is our basic level of protection, covering the components that move the vehicle such as the engine, transmission, and drivetrain.

Comprehensive Coverage

CarvanaCare Plus is our next level up, designed for those who prefer comprehensive coverage. This includes everything in our Essential plan, but also includes steering, heating, A/C, exhaust, and much more.

Premium Coverage

CarvanaCare Premier is our highest level of coverage, providing mechanical and cosmetic repairs. This plan includes everything in our Essential and Plus plans, but also includes **3 oil changes and tire rotations for 1 year**, minor cosmetic repairs, and tire/wheel damage.

Components covered by CarvanaCare

Essential Basic Mechanical Coverage	Plus Comprehensive Coverage	Premier Premium Coverage
<div>Transmission/Transfer Case<ul style="list-style-type: none">Accumulator PistonsAccumulator RingsAccumulator Seal BandsBearingsBell HousingBushingsCaseChainsCheck BallsCoolerCounter ShaftsDetent CableDrive LinkDrive PlateDrumsDust CapFlex PlateFront BandsGasketsGearsGovernorGovernor SupportImpeller HubInput ShaftInput TurbineIntermediate BandsInternal 4x4 ActuatorKickdown BandsKickdown ServoMain ShaftManual ShaftModulator ValveMultifunction ValvesOil PanOil PumpOil Pump CoverOutput GearsOutput ShaftOutput Shaft BearingsParking Lock SpragParking PawlPistonsPlanetary Gear CarrierPlanetary GearsInternal Pressure SensorsInternal Speed SensorsReaction Gear SetRear BandsReverse BandsReverse Servo</div> <div>Engine<ul style="list-style-type: none">Balance ShaftsBalance Shaft ChainsBalance Shaft SprocketsCam BearingsCam BoltsCam CoverCam FollowerCamshaftsCamshaft SprocketsCompression RingsConnecting RodsCrankshaftCrankshaft PulleyCrankshaft SprocketsCylinder Block</div> <div>Ring Gears<ul style="list-style-type: none">Roll PinsRoller ClutchesServo RingsShiftsShift CoverShift ForksShift ValvesSide CoverSnap RingsSpeedometer Drive GearSpeedometer Driven GearSpragsSpringsSprocket SupportsSprocketsStatorStator ShaftSun GearsSynchronizer HubSynchronizer RingsSynchrosInternal Temperature SensorThrust WashersThrottle ValveTorque ConverterTransaxleTransaxle CaseTransmission MountsTurbineVacuum ModulatorValve BodyValve Solenoids</div> <div>Cylinder Head Bolts<ul style="list-style-type: none">Cylinder HeadsEngine MountsExhaust ManifoldsExhaust ValvesFlex PlateHarmonic BalancerIntake ManifoldIntake ValvesIntermediate Shaft LiftersMain Bearing CapsMain BearingsOil PanOil Pressure Relief SpringOil PumpOil Pump GearsOil Pump PickupOil RingsPiston RingsPistonsPushrodsRocker Arm StudsRocker ArmsRod BearingsSilent ShaftSuperchargerTappetsThrust PinsTiming BeltTiming Belt TensionerTiming GearsTiming SprocketsTurbochargerValve CoversValve KeepersValve LiftersValve SeatsValve SpringsValve Stem GuidesValve Stem SealsWrist Pins</div> <div>Differential Cover<ul style="list-style-type: none">Differential HousingDrive ShaftHalf ShaftsLocking HubsPinion GearPositraction ClutchesRing GearsSide BearingsSide GearsSlip JointsSpider GearsUniversal JointsWheel BearingsYokes</div> <div>Electric/Hybrid<ul style="list-style-type: none">Drive Motor/GeneratorHigh Voltage BatteryInverterOn-Board Charger</div>	<div>Transmission/Transfer Case<ul style="list-style-type: none">Clutch Master CylinderClutch Pilot BearingClutch Slave CylinderClutch Throw Out BearingElectronic Shift Control UnitFlywheelPressure PlateRange SensorTransmission Control Module (TCM)Transmission Wiring HarnessSeals and Gaskets for Covered Components</div> <div>Engine<ul style="list-style-type: none">Engine Control Module (ECM)Engine Oil CoolerEngine Wiring HarnessOil Filter Adaptor HousingVariable Valve Timing ActuatorVariable Valve Timing SolenoidSeals and Gaskets for Covered Components</div> <div>Front/Rear Wheel Drive<ul style="list-style-type: none">Center Support BearingCV BootsDifferential CoversLocking HubsWheel/Hub BearingsSeals and Gaskets for Covered Components</div> <div>Fuel and Emissions<ul style="list-style-type: none">Evap CanisterFuel InjectorFuel Injection PumpFuel Level SensorFuel PumpFuel Pressure RegulatorFuel Rail Pressure SensorFuel Tank Sending UnitIntake Air Temperature SensorLeak Detection Pump</div> <div>MAP Sensor<ul style="list-style-type: none">Mass Air flow SensorPurge Valve/SolenoidThrottle BodyThrottle Position SensorSolenoid Vent ValveSeals and Gaskets for Covered Components</div> <div>Heating and A/C<ul style="list-style-type: none">A/C CompressorAccumulatorBlower MotorBlower Motor ResistorBlower Motor SwitchCompressor ClutchConsenserConsenser Fan MotorCoolant Heater ControllerEvaporator CoreExpansion ValveHeater CoreHVAC ActuatorsHVAC Control UnitHVAC Control HeadHybrid/Electric Coolant HeaterInterior/Exterior Temperature SensorOrifice TubeReceiver/DryerSeals and Gaskets for Covered Components</div> <div>Suspension<ul style="list-style-type: none">Ball JointsControl ArmsControl Arm BushingsControl Arm ShaftsElectric Level Control ActuatorElectronic Level Control CompressorElectronic Level Control Height SensorElectronic Level Control ModuleSpindlesStabilizer BarStabilizer Bar BushingsTorsion BarTorsion Bar BushingsTorsion Bar MountsTrack BarTrack Bar BushingsWheel BearingsYaw Rate SensorSeals and Gaskets for Covered Components</div> <div>Brake System<ul style="list-style-type: none">ABS AccumulatorABS Control ModuleABS Hydraulic Pump/Motor AssemblyABS Wheel Speed SensorsBrake BoosterCaliper(s)Master CylinderVacuum PumpWheel CylinderSeals and Gaskets for Covered Components</div> <div>Cooling System<ul style="list-style-type: none">Engine Cooling Fan ClutchEngine Coolant Level SensorEngine Coolant Temperature SensorThermostatTurbo Charger IntercoolerWater PumpRadiatorCooling Fan MotorSeals and Gaskets for Covered Components</div> <div>Electrical<ul style="list-style-type: none">HVAC Control ModuleAccelerator Pedal Position SensorAir Bag ModuleAir Bag SensorAlternatorBody Control Module (BCM)Camshaft SensorClock SpringConvertible Top MotorConvertible Top SwitchCrankshaft SensorDash Light Dimmer SwitchHazard Warning SwitchInstrument ClusterIgnition Coil/Coil PackIgnition ModuleIgnition Lock CylinderImpact SensorKeyless Entry ReceiverKeyless Entry RemoteKnock SensorOil Level SensorOil Pressure Sending UnitOxygen SensorPower Door Lock ActuatorsPower Hatch Lift MotorPower Mirror MotorPower Seat MotorsPower Window Motors and RegulatorsPowertrain Control Module (PCM)Rear Hatch MotorRear View CameraSliding Door MotorStarter MotorTire Pressure SensorsWindow Washer PumpWindow Wiper MotorWiring Harness</div> <div>Tire, Wheel & Dent<ul style="list-style-type: none">Dent and ding protectionTire repair due to damage from road hazardTire replacement due to damage from road hazardWheel repair due to damage from road hazardWheel replacement due to damage from road hazardCosmetic wheel repair</div> <div>Complimentary Maintenance<ul style="list-style-type: none">Change engine oilChange engine oil filterLubricate front suspensionLubricate steering linkageLubricate ball jointsMultipoint inspectionRotate tires</div> <div>Important, please read:<p>Every effort has been made to provide a complete list of covered components. Exclusions and limitations apply, refer to your contract terms and conditions for details and limitations.</p><p>In Florida, CarvanaCare is provided by SilverRock Automotive of Florida, Inc., P.O. Box 29087, Phoenix, AZ 85038-9087, Florida License #30847</p></div>	